



SPEAKER SWITCH BOARD

The speaker switch board allows for the use of and I/O source to be switched. The continuous audio source "A" is interrupted by the "B" audio source. Typical uses are with voice annunciator, intercom and elevator music.

