



ALTERNATE MESSAGE MODULE

The alternate message module was designed to be used in conjunction with the MCCU4-XX controller and the AMCUX-XX voice module. The message module provides you with 8 prioritized messages that when used with MCCU4-XX controller would alternate with the floor indication. An example would be emergency stop. "ES" would then alternate with the appropriate floor designation. These indications are helpful when trying to diagnose a problem of non-movement of your elevators.

Features:

- Easy installation
- Increased flexibility
- Improved diagnostics
- Low cost
- 8 prioritized messages
- A17 ANSI fire service inputs

TO ORDER: - MAMM1 - X

SIGNAL VOLTAGE:

- "A" = POSITIVE 6-20VAC/DC, 24VAC
- "B" = POSITIVE 24-48VDC, 24-48VAC
- "C" = POSITIVE 120VAC
- "D" = POSITIVE 125VDC
- "E" = NEGATIVE 6-20VDC
- "F" = NEGATIVE 24-48VDC
- "G" = NEGATIVE 125VDC

NOTE:

1. If a special voltage is required, please consult factory.