OTIS


"E" = OEMS

TYPE:

"M" = MAIN

"R" = REMOTE

Ver. 1 Rel. 06/01/04



5.45"

Power Supply Studs Placement

"V" = VIDEO

"A" = AUXILIARY PANEL LINK

DRIVER OPTIONS:

5.25

OEMS-X

USE OEMS-X ONLY IF 411 SYSTEM IS USING THE EMS OPTION

3.5

OCDL-X